

Swinburne University of Technology

*COS20019 Cloud Computing Architecture*





---


## Lab 5 - Build a Database Server

---

*Saturday 7th October, 2023*



# Task 1: Create a Security Group for the RDS DB Instance

Step	Description	Screenshot
1	In the <b>AWS Management Console</b> , on the Services menu, choose <b>VPC</b> .	
2	In the left navigation pane, choose <b>Security Groups</b> . Choose Create security group and then configure: <ul style="list-style-type: none"> <li>• <b>Security group name:</b> DB Security Group</li> <li>• <b>Description:</b> Permit access from Web Security Group</li> <li>• <b>VPC:</b> <i>Lab VPC</i></li> </ul>	
3	In the <b>Inbound rules</b> pane , choose Add rule. Configure the following settings: <ul style="list-style-type: none"> <li>• <b>Type:</b> <i>MySQL/Aurora (3306)</i></li> <li>• <b>CIDR, IP, Security Group or Prefix List:</b> Type sg and then select <i>Web Security Group</i>.</li> </ul>	
4	Choose <b>Create security group</b>	




# Task 2: Create a DB Subnet Group




Step	Description	Screenshot
5	On the Services menu, choose <b>RDS</b> .	<p>The screenshot shows the AWS Services search results for "rds". The "RDS" service is highlighted, with the description "Managed Relational Database Service".</p>
6	<p>In the left navigation pane, choose <b>Subnet groups</b>. Choose Create DB Subnet Group then configure:</p> <ul style="list-style-type: none"> <li>• <b>Name:</b> DB-Subnet-Group</li> <li>• <b>Description:</b> DB Subnet Group</li> <li>• <b>VPC:</b> <i>Lab VPC</i></li> </ul>	<p>The screenshot shows the "Create DB subnet group" page in the Amazon RDS console. The "Subnet group details" section is visible, showing the following configuration:</p> <ul style="list-style-type: none"> <li><b>Name:</b> DB-Subnet-Group</li> <li><b>Description:</b> DB Subnet Group</li> <li><b>VPC:</b> Lab VPC (vpc-061cd613bdaeb0bca)</li> </ul>
7	<p>Scroll down to the <b>Add Subnets</b> section.</p> <p>Expand the list of values under <b>Availability Zones</b> and select the first two zones: <b>us-east-1a</b> and <b>us-east-1b</b>.</p> <p>Expand the list of values under <b>Subnets</b> and select the subnets</p>	





	<p>associated with the CIDR ranges <b>10.0.1.0/24</b> and <b>10.0.3.0/24</b>.</p> <p>These subnets should now be shown in the <b>Subnets selected</b> table.</p>	 <table border="1"> <thead> <tr> <th>Availability zone</th> <th>Subnet ID</th> <th>CIDR block</th> </tr> </thead> <tbody> <tr> <td>us-east-1b</td> <td>subnet-0943f79b8d24351f8</td> <td>10.0.3.0/24</td> </tr> <tr> <td>us-east-1a</td> <td>subnet-0d1362523d296c476</td> <td>10.0.1.0/24</td> </tr> </tbody> </table>	Availability zone	Subnet ID	CIDR block	us-east-1b	subnet-0943f79b8d24351f8	10.0.3.0/24	us-east-1a	subnet-0d1362523d296c476	10.0.1.0/24
Availability zone	Subnet ID	CIDR block									
us-east-1b	subnet-0943f79b8d24351f8	10.0.3.0/24									
us-east-1a	subnet-0d1362523d296c476	10.0.1.0/24									
8	Choose <b>Create</b>	 <table border="1"> <thead> <tr> <th>Name</th> <th>Description</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>db-subnet-group</td> <td>DB Subnet Group</td> <td>Complete</td> </tr> </tbody> </table>	Name	Description	Status	db-subnet-group	DB Subnet Group	Complete			
Name	Description	Status									
db-subnet-group	DB Subnet Group	Complete									



## Task 3: Create an Amazon RDS DB Instance

Step	Description	Screenshot						
9	<p>In the left navigation pane, choose <b>Databases</b>. Choose Create database Select <b>MySQL</b> under <b>Engine Options</b>.</p>	 <table border="1"> <thead> <tr> <th>Name</th> <th>Description</th> <th>Status</th> </tr> </thead> <tbody> <tr> <td>db-subnet-group</td> <td>DB Subnet Group</td> <td>Complete</td> </tr> </tbody> </table>	Name	Description	Status	db-subnet-group	DB Subnet Group	Complete
Name	Description	Status						
db-subnet-group	DB Subnet Group	Complete						




11	<p>Under <b>Settings</b>, configure:</p> <ul style="list-style-type: none"> <li>• <b>DB instance identifier:</b> lab-db</li> <li>• <b>Master username:</b> main</li> <li>• <b>Master password:</b> lab-password</li> <li>• <b>Confirm password:</b> lab-password</li> </ul>	
12	<p>Under <b>DB instance class</b>, configure:</p> <ul style="list-style-type: none"> <li>• Select <b>Burstable classes (includes t classes).</b></li> <li>• Select <i>db.t3.micro</i></li> </ul>	
13	<p>Under <b>Storage</b>, configure:</p> <ul style="list-style-type: none"> <li>• <b>Storage type:</b> <i>General Purpose (SSD)</i></li> <li>• <b>Allocated storage:</b> 20</li> </ul>	





14	<p>Under <b>Connectivity</b>, configure:</p> <ul style="list-style-type: none"> <li><b>Virtual Private Cloud (VPC):</b> <i>Lab VPC</i></li> </ul>	
15	<p>Under <b>Existing VPC security groups</b>, from the dropdown list:</p> <ul style="list-style-type: none"> <li>Choose <i>DB Security Group</i>.</li> <li>Deselect <i>default</i>.</li> </ul>	
16	<p>Expand <b>Additional configuration</b>, then configure:</p> <ul style="list-style-type: none"> <li><b>Initial database name:</b> lab</li> <li>Uncheck <b>Enable automatic backups</b>.</li> <li>Uncheck <b>Enable encryption</b></li> <li>Uncheck <b>Enable Enhanced monitoring</b>.</li> </ul>	
17	Choose Create database	

		
18	<p>Choose <b>lab-db</b>. Wait until <b>Info</b> changes to <b>Modifying</b> or <b>Available</b>. Scroll down to the <b>Connectivity &amp; security</b> section and copy the <b>Endpoint</b> field.</p> <p><b><i>lab-db.c8wkkok2ubu9.us-east-1.rds.amazonaws.com</i></b></p>	

## Task 4: Interact with Your Database

Step	Description	Screenshot
19	To copy the <b>WebServer</b> IP address, choose on the Details drop down menu above these instructions, and then choose Show.	



20	<p>Open a new web browser tab, paste the <i>WebServer</i> IP address and press Enter.</p> <p>Choose the <b>RDS</b> link at the top of the page.</p>	
21	<p>Configure the following settings:</p> <ul style="list-style-type: none"> <li>• <b>Endpoint:</b> lab-db.c8wkkok2ubu9.us-east-1.rds.amazonaws.com</li> <li>• <b>Database:</b> lab</li> <li>• <b>Username:</b> main</li> <li>• <b>Password:</b> lab-password</li> <li>• Choose <b>Submit</b></li> </ul>	
22	<p>A message will appear explaining that the application is running a command to copy information to the database. After a few seconds the application will display an <b>Address Book</b>.</p> <p>The Address Book application is using the RDS database to store information.</p>	
23	<p>Test the web application by adding, editing and removing contacts.</p>	

**END LAB.**